


Non-Sterile Cleanroom Gowning Procedure

STEP 1: PRE-ENTRY



Bouffant/Hair Net
Be sure to contain all hair.



Shoe Covers
Contain all laces and tassels.




STEP 2: GOWNING



Gowning Gloves
Recommended for Class 100 and better.



Mask Worn over or under hood. Bend nosepiece first for a snug facial fit.




Hood
Ensure snug fit and proper face/neck seal.



STEP 3

Coverall
Step into the coverall. Be sure sleeves and upper garment do not touch bench or floor.


Tuck shoulder panels from hood inside coverall before zipping up.



STEP 4


Boot Covers
Put on boots and pull boots (high-top shoe covers) over legs of coverall.

If cross-over bench is used, transfer each foot to cleaner side of bench as boot is donned.



STEP 5

Goggles Wear goggles/safety glasses when eye protection or additional particulate control is desired.



STEP 6

Cleanroom Gloves (optional)
Place hem of glove over cuff of sleeve. Put on over gowning gloves or remove gowning gloves and then put on cleanroom gloves.




Non-Sterile Cleanroom Gowning Removal Procedure


STEP 1: IN ORDER




Gloves
If two pairs of gloves are worn, remove top pair of gloves, then discard.




Goggles/Safety Glasses
Remove and properly contain.




Boot Covers
Usually discard after each change.



STEP 2




Coverall If coverall is to be used again, either hang it in a controlled environment or prepare for storage.




Hood Hang in controlled environment.




Mask Remove and usually discard.




STEP 3



Gloves It is recommended that gloves be discarded after each change.



Bouffant/Hair Net
Usually discard after each change.



Shoe Covers
Usually discard after each change.